

**Kiilto
PRO**

Kiilto Pro MD Block

replace empty package in 3 easy steps

Replacing empty MD Block packages with new ones is done quickly and safely. Always remember to use protective equipment in accordance with the instructions.



step 1

REMOVE THE EMPTY PACKAGE

The dosing device will alarm once the package is empty. There will be a **sound notice** and the **red light will be lit up**. Do not remove the package until it is completely empty.



step 2

REMOVE THE CAP FROM THE NEW PACKAGE

The cap can be removed by lightly lifting it from one side.



step 3

PLACE THE NEW PACKAGE INTO THE DOSING DEVICE

The new package should be placed in a way that the handle of the package is pointed out of the wall. Please make sure that the Kiilto Pro MD Block is correctly in its place by pushing it all the way down.

Kiilto Pro MD Block -products:



Kiilto Pro MD Block S
4,95 kg / 63177



Kiilto Pro MD Block Extra
4,95 kg / 63178



Kiilto Pro MD Block Alu
4,95 kg / 63159



Kiilto Pro MD Block Rinse
3 kg / 63033

