


Pro shine special

Furniture Polish





- Appropriate for all wood surfaces (like teak, oak and mahogany) as well as polished and painted surfaces
- Leaves a protective film against fingerprints, water rings and dust
- Emulsion system results in stability and streak-free application



Pro shine special

Furniture Polish

Product Description:

PRO SHINE SPECIAL is a furniture polish for wooden surfaces e.g Teak, Oak, Mahogany, as well as polished and painted surfaces. Treatment with PRO SHINE SPECIAL leaves a protective film against fingerprints, water rings and settled dust

PRO SHINE SPECIAL ensures a streak-free application with a pleasant scent.

Use Direction:





PRO SHINE SPECIAL is directly dispensed from its ready-to-use spray bottle. Shake before use.

- 1. Use sprayer to apply PRO SHINE SPECIAL sparingly onto a clean cloth.
- 2. Apply PRO SHINE SPECIAL evenly across the surface to be cleaned. Wipe surface dry with a clean cloth.

Safety:

For professional use only.

Keep out of reach of children.

For further information and safety instructions see product label and safety data sheet.

Packaging:

6 x 500 ml

Storage conditions:

Store between 0 and 35°C.

